

Shanghai Truer Technology Co., Ltd.

Shanghai Truer Technology Co., Ltd. (Truer Technology) is one of the subsidiaries of Truer group, which is mainly responsible for the export business. At present, the main products cover the raw materials, production equipment, inspection devices and service for additive

manufacturing (AM), Metal Injection Molding (MIM), Powder Metallurgy (PM), automation

and other manufacturing fields.

At present, we have 12 factories and more than 30 strategic partners in China for different

applications.

We take the lead in providing innovative desktop level plasma rotating electrode atomizing powder making equipment (SLPA-D) globally. The maximum rotation speed of consumable electrode rods can reach 50,000 rpm, which is very suitable for the preparation of small batch, multi variety and high-quality metal powders. Using this equipment, we and our customers have successfully developed more than 60 different compositions of high-quality spherical metal powders such as TiNi, Tita, TiAl, TiNbZr and CoCrMo. In addition, we also provide the medium-sized PREP metal powder making equipment (SLPA-N50) and large-scale metal powder making equipment (SLPA-N75), which are suitable for industrial production and provide high-quality metal powders with

reasonable cost for 3D printing and other applications.

We are committed to providing the suitable plasma rotating electrode atomizing metal powder making equipment or high-quality PREP metal powders to meet different customers' requirements, i.e. new material development, or production of high-quality parts, etc. We will continue to invest in R&D to optimize our plasma rotating electrode metal powder making equipment and production process, in order to provide customers with the best quality PREPed metal powders.


Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703

Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891 Email: sales@prep-system.com https://www.prep-system.com



Principle of Plasma Rotating Electrode Process (PREP)

The high-temperature plasma torch melts one end face of the high-speed rotating electrode rod (raw materials), then the molten metal liquid film flies out and breaks into droplets under the action of centrifugal force generated by high-speed rotation. Some droplets will collide with inert gas molecules and break into smaller droplets. All these droplets are gradually solidified under the action of surface tension during flight and become spherical, and finally they reach the wall of the atomizing chamber and are cooled into spherical metal powders.



Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703 Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891



Small-scale PREP system: SLPA-D



The small-scale PREP system (SLPA-D, desktop level) is purposely designed for R&D of novel alloy powders and small batch production of high quality powders with the following characteristics:

- ✓ Relatively lower cost for multi-small-batch production
- ✓ Quicker switch for multi-small-batch and diversified powder production (time reduction)
- ✓ Ergonomics friendly, easy to operate
- ✓ Simple and professional man-machine interface design
- ✓ High fine powders output rate due to high rotating speed (up to 50,000rpm).
- ✓ The produced powders have high sphericity (over 95%) and high quality, such as low porosity powders, low satellite powders, high purity (low oxygen increase, ≤ 100ppm) due to atomizing in the inert protection atmosphere.
- ✓ Can produce nearly all metal powders which rods are electro-conductive, specially for refractory metals, high-activity metals, super-alloys, etc.

Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703 Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891



Main Technical Parameters and Structure

Main Technical Parameters						
Rotating speed of electrode rod	Up to 50,000rpm (Adjustable)					
Diameter of Eletrode rod	Ф30mmx160mm					
Powder Morphology	Spherical Rate ≥95%					
Particle Size Distribution	D50≤43µm (Inconel 718)					
Capacity	≥10kg (8hrs, Inconel 718)					
Oxygen Increment	≤100ppm (Ti6Al4V ≤100ppm; Inconel 718 ≤50ppm)					
Atmosphere	Ar or He (high purity) or other inert gas					
Maximum power	120kW					
Machine size	4m x 3m x 2.5m					
Applications	Ti&Alloys, Ni&Alloys, Co&Alloys, Stainless steels, high entropy alloys, Cu& Alloys and refractory alloys					

Ma	Main Sub-systems						
1	Plasma gun system	In-house design and manufacturing					
2	High rotating speed shaft system and dynamic sealing mechanism	In-house design and outsourced					
3	Feeding system	In-house design and outsourced					
4	Powder collection system	In-house design and outsourced					
5	Atomization chamber	In-house design and outsourced					
6	Vacuum system	Outsourced					
7	Cooling system	In-house design and outsourced					
8	Gas supply system	In-house design and outsourced					
9	Power supply and Electrical control system	Outsourced					

Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703 Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891



Typical Particle Size Distribution of Metal Powders produced by SLPA-D

	Mesh	+100		-100/+1	40	-140/+	-200	-200	/+270	-27	70/+325		-325
Ti6Al4V	μm	>150		106-15	50	75-1	06	53	3-75	4	45-53		<45
	%	7.39		11.81		18.8	39	9 45.98			9.10		7.83
Inconel	Mesh	+100		-100/+1		-140/+)/+270		70/+325		-325
718	μm	>150		106-15	50	75-1			3-75		45-53		<45
	%	0.09		1.57		8.8	0	10).52		15.58		63.44
Divers	Mesh	+100		-100/+1	40	-140/+	200	-200	/+270	-27	0/+325	-3	325
Pure Tungsten	μ m	>150		106-150)	75-106	3	53-7	5	45-	-53	<	45
rangeten	%	0.0		3.6		23.1		43.0		12.	0	1	8.3
						•		•					
	Mesh	+100	-1	100/+150	-15	0/+200	-200/	+230	-230/+2	270	-270/+32	5	-325
CoCrMo	μm	>150	1	00-150	75	-100	75-1	06	53-75		45-53		<45
	%	0.0	3	3.4	11.	.3	14.8		20.2		8.0		42.3
							I						
High entropy	Mesh	+100	-1	100/+150	-15	0/+200	-200/	+230	-230/+2	270	-270/+32	5	-325
alloy AlCoNiCrCu	μ m	>150	10	00-150	75-	100	75-10	06	53-75		45-53		<45
AICONICICU	%	0.3	4	1.5	8.0)	25.1		20.8		22.7		18.6
	Mesh	+100		-100/+1	40	-140/+	200	-200	/+270	-27	0/+325	-3	325
CuCrZr	μ m	>150		106-150)	75-106	3	53-7	5	45-53		<	45
	%	0.0		3.0		30.8		37.1 1		11	.8	1	7.3
												_	
	Mesh	+100		-100/+1	40	-140/+	200	-200/+270		-270/+325		-3	325
316H	μm	>150		106-150)	75-106	3	53-7	5	45-53		<	45
	%	0.02		1.88		29.40		21.50 12		12	.50	3	34.70

Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703 Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891



Medium-scale PREP system: SLPA-N50



The medium-scale PREP system (SLPA-N50) is purposely designed for continuous, industrial mass production of high quality spherical metal powders with the following characteristics:

- ✓ Reasonable cost for medium-batch production
- ✓ Ergonomics friendly, easy to operate
- ✓ Simple and professional man-machine interface design
- ✓ Relatively high fine powders output rate (average rotating speed: 30,000rpm)
- ✓ The produced powders have high sphericity (over 90%) and high quality, such as low porosity powders, low satellite powders, high purity (low oxygen increase, ≤ 120ppm) due to atomizing in the inert protection atmosphere.
- ✓ Melting temperature ≥2600°C, suitable for produciton of Ti-alloys, Steels, Superalloys, Refractory alloys, high entropy alloys, etc.

Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703 Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891



Main Technical Parameters and Structure

Main Technical Parameters						
Rotating speed of electrode rod	Average 30,000rpm (Adjustable)					
Diameter of Eletrode rod	Ф50mmx260mm					
Powder Morphology	Spherical Rate ≥95%					
Particle Size Distribution	D50≤63µm (Ni-base superalloys) D50≤105µm (Ti-alloys) D50≤100µm (W-alloys)					
Capacity	≥80kg (8h, Ni-base superalloys) ≥40kg (8h, Ti-alloys) ≥100kg (8h, W-alloys)					
Oxygen Increment	≤120ppm					
Atmosphere	Ar or He (high purity) or other inert gas					
Maximum power	260kW					
Machine size	6m x 6m x 5m					
Applications	Ti&Alloys, Ni&Alloys, Co&Alloys, Stainless steels, high entropy alloys, Cu& Alloys and refractory alloys, etc.					

M	Main Sub-systems					
1	Plasma gun system	In-house design and manufacturing				
2	High rotating speed shaft system and dynamic sealing mechanism	In-house design and outsourced				
3	Feeding system	In-house design and outsourced				
4	Powder collection system	In-house design and outsourced				
5	Atomization chamber	In-house design and outsourced				
6	Vacuum system	Outsourced				
7	Cooling system	In-house design and outsourced				
8	Gas supply system	In-house design and outsourced				
9	Power supply and Electrical control system	Outsourced				

Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703 Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891



Typical Particle Size Distribution of Metal Powders produced by SLPA-N50

	Mesh	+60	-60/+100	-100/+140	-140/+200	-200/+270	-270/+325	-325
Ti6Al4V	μ m	>250	150-250	106-150	75-106	53-75	45-53	<45
	%	0.5	14.6	50.3	22.7	8.7	1.7	1.5
	Mesh	+60	-60/+100	-100/+140	-140/+200	-200/+270	-270/+325	-325
Ti2AlNb	μm	>250	150-250	106-150	75-106	53-75	45-53	<45
	%	1.2	2.5	21.1	29.2	32.8	6.7	6.5
Incorpol	Mesh	+60	-60/+100	-100/+140	-140/+200	-200/+270	-270/+325	-325
Inconel 718	μm	>250	150-250	106-150	75-106	53-75	45-53	<45
	%	0	3.9	16.7	19.8	45.1	8.9	1.7
	Mesh	+60	-60/+100	-100/+140	-140/+200	-200/+270	-270/+325	-325
TiAl4822	μm	>250	150-250	106-150	75-106	53-75	45-53	<45
	%	9.8	30.2	30.9	19.7	7.7	0.9	0.8
	Mesh	+60	-60/+100	-100/+140	-140/+200	-200/+270	-270/+325	-325
Inconel 625	μm	>250	150-250	106-150	75-106	53-75	45-53	<45
	%	0	0.7	5.2	15.6	49.9	15.3	13.3
	Mesh	+60	-60/+100	-100/+140	-140/+200	-200/+270	-270/+325	-325
Zr2.5Nb	μm	>250	150-250	106-150	75-106	53-75	45-53	<45
	%	0.10	11.06	39.59	33.67	11.78	2.14	1.66

Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703 Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891



Large-scale PREP system: SLPA-N75



The large-scale PREP equipment (SLPA-N75) is purposely designed for continuous, industrial mass production of high quality spherical Titanium alloy powders with the following characteristics:

- ✓ Reasonable cost for large-batch production
- ✓ Ergonomics friendly, easy to operate
- ✓ Simple and professional man-machine interface design
- ✓ Relatively lower fine powders output rate (rotating speed up to 22,000rpm)
- ✓ The produced powders have high sphericity (over 90%) and high quality, such as low porosity powders, low satellite powders, high purity (low oxygen increase, ≤ 120ppm) due to atomizing in the inert protection atmosphere.
- Suitable for production of metal powders with melting point \leq 2,600 $^{\circ}$ C, mainly for Titanium alloys.

Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703 Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891



Main Technical Parameters and Structure

Main Technical Parameters						
Rotating speed of electrode rod	Up to 22,000rpm (Adjustable)					
Diameter of Eletrode rod	Ф75mmx360mm					
Powder Morphology	Spherical Rate ≥90%					
Particle Size Distribution	TA15: -150µm≥75%					
Capacity	≥100kg (8h, TA15)					
Oxygen Increment	≤120ppm					
Atmosphere	Ar or He (high purity) or other inert gas					
Maximum power	300kW					
Floor Space	8m x 8m x 6m					
Applications	Ti&Alloys, Ni&Alloys, Co&Alloys, Stainless steels, high entropy alloys, etc.					

Ма	Main Sub-systems						
1	Plasma gun system	In-house design and manufacturing					
2	High rotating speed shaft system and dynamic sealing mechanism	In-house design and outsourced					
3	Feeding system	In-house design and outsourced					
4	Powder collection system	In-house design and outsourced					
5	Atomization chamber	In-house design and outsourced					
6	Vacuum system	Outsourced					
7	Cooling system	In-house design and outsourced					
8	Gas supply system	In-house design and outsourced					
9	Power supply and Electrical control system	Outsourced					

Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703 Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891




Typical Particle Size Distribution of Metal Powders produced by SLPA-N75

	Mesh	+60	-60	-100		
TA15	μ m	>250	<250	<150		
	%	≤5.0	≥95.0	≥75.0		


Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703 Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891



Typical Morphology of Metal Powders produced by PREP systems



AlSi10Mg powders produced by PREP system




Ti6Al4V (TC4) powders produced by PREP system


Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703 Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891

Email: sales@prep-system.com https://www.prep-system.com






High purity Ti powders produced by PREP system




In718 powders produced by PREP system

Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703 Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891





Refractory Metal and Alloy powders produced by PREP system



Steel Alloy powders produced by PREP system

Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703 Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891

Email: sales@prep-system.com https://www.prep-system.com



Example characteristics of metal powders produced by PREP system

No.	Material code	Oxygen in raw material rods	Oxygen in metal powders	Oxygen increase
1	Ti48Al2Cr2Nb	470	560	90
2	Ti45Al8Nb	580	650	70
3	Nb521	150	250	100
4	Мо	35	100	65
5	Та	40	10~30	-10↓

No.	Material code	Flow rate (s/50g)	Apparent density (g/cm3)	Tap density (g/cm3)
1	Ti48Al2Cr2Nb	28.3	2.39	2.59
2	Ti45Al8Nb	28.6	2.55	2.70
3	Nb521	11.8	5.33	5.88
4	Мо	9.9	6.10	6.58
5	Та	6.0	9.97	10.60

Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703 Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891



Thank you for your attention!

Shanghai Truer Technology Co.,Ltd

No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703

Tel: +86-21-34320902

Mobile: +86-15250014048 / 15250232891 / 13611869448 / 17316565943

Email: luke.zhang@prep-system.com / <u>lucy.wen@prep-system.com</u> /

cassiel.ding@prep-system.com / joan.zhou@prep-system.com

https://www.prep-system.com

Address: No. 299, Songqiu Road, Qingpu District, Shanghai, China 201703 Tel: 021-34320902 Mobile:+86-15250014048 / 15250232891